



Omniksol WIFI Kit User Manual

Omnik New Energy Co., Ltd.



Overview of WiFi Kit Functions

Omniksol WIFI Kit is developed by Omnik as an external communication monitoring device, which integrates WiFi functions for users to monitor their systems remotely.

By connecting with inverters through RS485 interface, the kit can receive information from inverters and realize cascade of inverters. It can connect to the router both wirelessly or through network cable so as to transfer inverter data to the web server.

Users can monitor the runtime status of the device by checking the 4 LEDs on the panel which indicates Power, RS485, Link and Status respectively.



Catalog


1. Unpack	4
2. The installation of data collector	4
3. Connection between data collector and inverter	5
4. WiFi settings	7
5. Debug	11
6. Register on monitoring website	14
7. Login the PV monitoring system to manage the power station	17
8. Contacts	25



1. Unpack

After unpacking the box, please check the parts according to the below list. Contact the manufacturer immediately, should you find any damage, missing or wrong model of the device or any parts.

Serial	Name	Quantity	Model
Α	PV data collector	1	WiFi kit
В	power supply adapter	1	FY0502000
С	screw	2	
D	expanded rubber tube	2	-
Е	manual	1	




2. The installation of data collector

2.1. Wall-mounted installation

- 1. Mark two horizontal round holes which distance is 69mm in the selected position;
- 2. Drill two φ6mm holes in the marked position, the depth of the hole is not less than 30mm;
- 3. Punch the expanded rubber tubes into the holes lightly with a rubber hammer;
- 4. Wring two screws into the expanded rubber tubes, the screws head exposed wall about 6cm;
- 5. Hang the PV data collector WiFi kit on the screws (refer to the picture).

Note: Note: The protection level of PV data collector WiFi kit is IP21. It cannot be installed outdoors or in the conditions of damp, dusty or with corrosive steam. Direct sunlight is also avoided. In addition, as metal components have effect on the wireless signals, the antenna of PV data collector (in all direction) should be away from metal components at least 10cm.



Picture2

2.2. Horizontal data collector installation

Lay the data collector on a flat surface.



Note: Note: The protection level of PV data collector WiFi kit is IP21. It cannot be installed outdoors or in the conditions of damp, dusty or with corrosive steam. Direct sunlight is also avoided, as well as shock and pressure defense. In addition, as metal components have effect on the wireless signals, the antenna of PV data collector (in all direction) should be away from metal components at least 10cm.


3. Connection between data collector and inverter

3.1. the instructions of data collector interface and connection line interface

serial	instructions		
Α	RS485/422 interface		
В	Ethernet		
С	Reset		
D	SVDC power port		
E	Antenna		



Picture 3



Line sequence of T568B

- 1. orange with white
- 2. orange
- 3. green with white
- 4. blue
- 5. blue white white
- 6. green
- 7. brown with white
- 8. brown

Picture 4

Pin NO.	RS485	RS422
1	NC	NC
2	NC	NC
3	NC	RX+
4	Α	TX+
5	В	TX-
6	NC	RX-
7	GND	GND
8	GND	GND



3.2. Steps of connection


Both ends of the connecting wire are RJ45 network cable connector, all the line sequence are T568B.

3.2.1 Single inverter connection

- 1. cut of the power supply of the inverter;
- 2. Insert the network cable into anyone RJ45 port on anyone inverter;
- 3. Let the other network cable connects the network interface of PV data collector WiFi kit.
- 4. Connect the power supply adapter to data collector, then insert into the socket

3.2.2 Multiple inverter connection

- 1. cut of the power supply of the inverter;
- 2. Insert the network cable into anyone RJ45 port on anyone inverter;
- 3. Insert the other network cable into anyone RJ45 port on second inverter;
- 4. Make the needed monitoring inverters in series in the same way;
- 5. Connect the PV data collector WiFi kit to a inverter with the bus, (constitute serial LAN);
- 6. Connect the power supply adapter to data collector, then insert into the socket




Picture 5


Note: Must cut off the power supply before connection. Please make sure that all the connections are completed, and then power the inverters and PV data collectors. Or may cause personal injury or equipment damage.




4. WiFi settings

























Picture 6



5. Ethernet connection




Step 1: Connect inverter, WIFI kit and your router with reticle (cable), and do not need to set anything.

Step 2: Reset, if you have used the WIFI function.



6. Debug

LED indicating lamp Introductions



Picture 7

Name of LED	Status	Description of status	
POWER	Light	The power is normal	
POWER	Dark	The power is abnormal	
	Light	The connection between collector and inverter is normal	
485\422	Flashing	Data is transferring between collector and inverter	
	Dark	The connection between collector and inverter is abnormal	
STATUS Dark	LINK Flashing	Connecting WiFi	
	LINK Flashing	Data is transferring of WiFi	
STATUS Light	LINK Light	The connection of collector is normal	
	LINK Dark	The connection of collector is abnormal	
	LINK Flashing	Data is transferring of port	
STATUS Flashing	LINK Light	WiFi is in the AP way , a terminal is connecting with the equipment	
	LINK Dark	WiFi is in the AP way , <i>no</i> terminal is connecting with the equipment	



Trouble shootings with LEDs

phenomenon					
POWER	485/422	LINK	STATUS	Possible reasons	Dealing ways
Dark	Dark	Dark	Dark	Haven't connected to the power	Connect power and ensure that the power supply is good.
Light	Dark	X	X	The connection of inverter is abnormal	Check the connection cable is right and ensure that the order is according to 568-B Ensure the stability of RJ-45 connector line Confirm the status of inverter and ensure it's working condition is normal
Light	х	х	Flashing	In the AP Mode	Set network settings
Light	х	Flashing	Dark	Collector is not connected with WIFI	Confirm if the antenna is loose or fall off. If so, please screw it. Check if the WIFI wanted is covered.
		D. I			Restore the factory settings according to the installation manual and reset.
Light	Light	Dark	Light	Fail to connect the remote server	Please confirm that WIFI can be connected with the Internet.
Light	Dark	Dark	Dark	The system is initialized	Please wait. If there is no change in 2min, please reset the collector.

Note1:x means the status is instability

Note2: If the equipment still cannot work according to the above instructions, please connect your device customer service.



7. Register on monitoring website


Our products supported by PV monitoring system Web site browser: IE8, Firefox, Chrome, safari, log into the website http://www.omnikportal.com, Click on register, enter the user registration page, follow the requirements for registration, after successful registration, enter the mailbox and activity the account, then complete the registration.

6.1 Click Register button to go to registering interface for new account



Picture 6-1

7.2 Fill in user's information as required




Picture 6-2



6.2.1

Remarks: please read the <Omnik service agreement >carefully, the enclosure is the cost list for all the countries, please choose your operators

Owner means the final user; Installer means the installer or distributor




Picture 6-3

6.2.2 "Installer" Account

register



Installer



Picture 6-4



Picture 6-5




7. Login the PV monitoring system to manage the power station

After the successful register and account activation, open the login interface as below picture 7-1, input the correct email and code and enter the PV monitoring system, then you can monitor and manage the power station.




Picture 7-1

7.1 "Owner" User Interface




Picture 7-2






Picture 7-3 List of power stations




Picture 7-4 navigation bar






Picture 7-5 Main interface of power station






Picture 7-7 History Interface






Picture 7-9 System Setting Interface






Picture 7-10 System Setting Interface


7.2 "Installer" User Interface








Picture 7-11 Home main interfaces



Picture 7-12





Picture 7-13



8. Contacts

If you have any technical problems about our products, please contact us, you should confirm the follow things before contact us:

- ◆ Device model
- ◆ Data collector serial number
- ◆ The number of connected inverter

Add: Xinghu Road No.218 bioBAY Park C2, Suzhou China

Zip code: 215213

Fax: +86 512 6295 6682 Tel: +86 512 6295 6676

Mail: Sales@omnik-solar.com